

Replaceable Cast in Place

Installation Instructions

The following instructions apply to Access[®] Tile's Replaceable Cast in Place tiles as well as the Radius Curve and Wayfinding version of these tiles.

1. Maintaining a 4-7 slump range, pour and float the concrete.
2. Without removing any concrete, place the tile 6"-8" from the curb line (face of curb).
3. Tamp the tile in grid pattern across the top face, embedding the tile into the concrete using a non-marring rubber mallet.
4. Place sandbags or 25 lb. weights on the tile to prevent floating, and create an edge around the perimeter of the tile using a 3/8" radius edging tool then float the concrete around the tile's perimeter using a steel trowel.
5. Apply a broom-finish to the surrounding concrete.
6. After the concrete has substantially cured, remove the protective plastic wrap by cutting the plastic with a sharp knife tight to the concrete/tile interface.

NOTE: If concrete bled under the plastic, a soft wire brush will remove residue without damaging the tile.

Replacement Instructions

- A. Unscrew T27 tamper-proof fasteners.
- B. Tap perimeter of tile with a rubber mallet to remove bond of tile to concrete.
- C. Use a pry bar to pry up an edge. Remove all debris from vacant cavity mold. Vacuum/sweep all crevices.
- D. Insert replacement tile, gently apply pressure to seat tile in recess. Reinsert tamper-proof fasteners in hex shape concrete anchors.

Tiles can be cut to custom sizes, or to make a radius, using a continuous rim diamond blade in a circular saw or mini-grinder. Use of a straightedge to guide the cut is advisable where appropriate.

