

Modular Paver

Installation Instructions

1. Prepare the concrete ensuring that the surface is clean, dry, free of voids, curing compounds, projections, loose material, dust, oils, grease, sealers and determined to be structurally sound before the application of the adhesive or thin-set mortar bed.
2. Apply a thin-set mortar bed or spread the structural adhesive to provide complete coverage over the prepared concrete surface using a clean, well-maintained 6mm x 6mm V notch trowel. The paver can be levelled with shims as required.
3. Maintain a 3mm gap between adjacent tiles.
4. Repeat the installation procedure for each tile.
5. Place a closed cell foam backing rod in-between each tile to a depth that allows a 12mm deep line of caulking.
6. Mechanically etch the area of the tile to be caulked using sandpaper and clean the perimeter of the tile and the immediate surrounding with acetone.
7. Tape the edges of the tile and concrete leaving a 12mm gap back from the tile's perimeter edge.
8. Apply caulking ½" minimum deep in between tiles and at the front face of the tile using Tactile Bond and Seal.
9. Using a plastic applicator or spatula smooth out the sealant in a cove profile between the tiles and the adjacent concrete.
10. Carefully remove masking tape immediately after tooling the perimeter sealant.